

Installation Procedures



Introduction

Infinity MAX™ must be installed correctly in order to maintain the 10 year material warranty. It is **imperative** that all tiles be installed under compression to create a tight seam between the tiles. Failure to install the Infinity MAX™ system under compression to the dimensions outlined in the attached **Table** will void the systems warranty. By carefully following the instructions below you will be able to achieve the required compression during installation.

The Layout

When preparing the initial site layout there are important factors to take into consideration:

- Each Infinity MAX™ tile is manufactured to a nominal dimension of 24" x 24" from the factory
- The Infinity MAX[™] installation process requires that each tile be installed under compression to a finished dimension of 23 7/8″ (compressed 1/8th inch per tile)
- For installation efficiency, you may wish to pre-mark your tape measure in 23 7/8" increments based on the attached compression chart
- It is unlikely that the site is perfectly square or exactly as shown in the drawings

To ensure a visually proportionate site, lay the surface out with similar dimension cuts on all four sides of the floor. **When possible, cut tiles should be a minimum of 10" in width.**

FULL GLUE DOWN INSTALLATION METHOD

Each Infinity MAX™ tile measures approximately 24" X 24" from the factory.

After they are installed under compression they must measure 23 7/8" X 23 7/8" meaning each tile must be compressed by 1/8th inch.

Since each individual Infinity MAX™ tile must be compressed by 1/8th inch, the cumulative compression over a large floor span can best be achieved by breaking the total area into smaller more workable grid sections.

The following guidelines have been prepared to ensure that your installation is properly compressed using a minimal amount of

effort. This advanced installation technique will introduce new terminology and concepts involving the use of keystone tiles, strategic rows of tiles and compression rows.

Note: The installation techniques outlined in the following sections are mandatory to ensure the surface has been installed to specification and to validate the warranty.

A - Locate the Center Line of the Room

Locate, measure and chalk line the vertical and horizontal center lines in the room. Center lines should be shifted based on the best visual effect on the perimeter cuts. When possible perimeter cuts should be a minimum of 10 inches in width (*Fig. 1*).




Fig. 1




Fig. 2

- 1 -


B - Striking Lines


From the center point in the room strike chalk lines in 23 7/8 inch increments across the room in both directions so that a grid pattern has been created across the entire room (*Fig. 2*).

C - Install Keystone Tiles

Tiles that are permenantly fastened to the subsurface in strageic locations throughout the installation are referred to as keystone tiles. Keystone tiles are fastened to the floor using the adhesive supplied with the order. See adhesive section at the back of the book for detailed instructions. The purpose of keystone tiles is to provide a fixed point of compression for the strategic tile rows.

Using the adhesive method at the back of the book, adhere keystone tiles in each of the four corners of the installation. Since perimeter cuts can be placed last, each keystone tile should represent a full tile (*Fig. 3*).





Continue to place and secure keystone tiles every 7th tile throughout the installation (6 tiles spaces between keystones tiles) (Fig. 4).



Note: Keystone tile adhesive must cure enough to prohibit movement before strategic tiles rows are placed. Average set time is 4 hours based on temperature and humidity.

D - Install Strategic Tile Rows

Strategic rows of tiles are compressed between the keystone tiles. Installation of strageic rows assists in breaking large sites into smaller areas that are much easier to compress into place.

a) Begin by trowelling the factory supplied adhesive in a continuous 12 inch wide strip through the center of the grid lines where the strategic tiles rows will be placed (*Fig. 5*). The outer 6 inch edge of each tile must not be adhered at this point in the installation in order to allow compression of these tiles during the next installation step. The outer 6 inches of each tile will receive adhesive during the installation of the field tiles.






Fig. 5

- b) Install strategic rows of tiles beginning at opposite ends of the keystone tiles working inwards towards the center (*Fig. 6*).
- c) The final tile located in the middle of the strategic row is the compression tile and must be compressed into a space smaller than the tile. The process of compressing the tile into this space will force the other tiles to compress in each direction (*Fig. 7*).
- d) The locking mechanism on each edge of the tile should be engaged with the adjacent tile forcing the tile to buckle upwards. Once the locks are engaged, force the tile flat by applying downward pressure onto the tile (*Fig. 8*).
- e) The tile must be compressed into each strategic row within the adhesive working time to ensure the tiles are able to move before the adhesive cures.






E - Install Compression Rows

Compression rows are defined as the rows of tiles installed in the center of the strategic rows forming a cross hair in the center of each grid. Compression rows must be installed after the strategic row adhesive has fully cured and before the field tiles are installed.

Note: EDGE ADHESION IS OF UTMOST IMPORTANCE. Prior to installing the compression rows, adhesive must be troweled under the remaining edge portion of the compression tiles around the inner perimeter (Fig. 9).

Continue by troweling the factory supplied adhesive within the entire grid lines where the compression rows will be placed. Ensure that the adhesive spread covers 100% of the tile area extending to the the outer edge of the tile (*Fig. 10*).






Fig. 10

Install compression rows forming a cross hair in the center of each grid (*Fig. 11*).





Fig. 11

Fig. 7

F - Installing Field Tiles

The remaining tiles to be installed are referred to as the field tiles. Install field tiles according to the diagram shown in *Fig. 14*.

Note: As in Fig. 12, all loose tiles edges around the inner perimeter of each grid must receive adhesive before installing the field tiles. Lift the loose edge of the strategic tile rows and trowel adhesive to the edge of the tile. Ensure that tiles are placed within 20 minutes of troweling the adhesive by installing one grid at a time.



Proceed by troweling the factory supplied adhesive onto the remaining areas where the field tiles will be placed and ensure 100% tile coverage (*Fig. 13*).




Fig. 13

G - Cutting in the Perimeter

At each seam location along the chalk line around the perimeter of the room, measure the distance from the perimeter tile edge to the wall and add 1/16" to this measurement. Transfer these measurements onto the tile (*Fig. 15*).

Cut tiles with a razor blade knife and metal straight edge on the line but with a back-cut or under-cut of approximately 5 degrees Trowel adhesive into the perimeter void where cut tiles will be placed. Install the cut tiles all the way around the perimeter. Start at the corners and work around (*Fig. 16*).




Fig. 14




Fig. 15




Fig. 16

H - Transitional Ramp Installation

If transitional ramps are being utilized on one or more sides they must be permanently secured to the floor using the adhesive application method below.

ADHESIVE INSTRUCTIONS

Depending on the size and scope of your project different adhesives may be supplied with the order:

- Sika 221 is supplied for installations that require less than 2 gallons
 of adhesive. Sika 221 is supplied in 600 ml sausage tube format
 and will need to be dispensed using the adhesive gun supplied
 with the order.
- Greenfusion is supplied on installations that require more than 2 gallons of adhesive. Greenfusion is supplied in 4 gallon pails.

Ramp Edge Adhesion


Prior to beginning the adhesive application process, measurements should be verified to ensure that the ramp edge pieces are placed in the exact position required based on the compression table and floor layout.

Adhere transition pieces by placing the manufacturer supplied adhesive between the transition edge and sub-floor. If using Sika 221, begin by dispensing several large beads of adhesive from the tube onto the subsurface.

Finish the adhesive using a 1/8th inch V-notched trowel to obtain 100% coverage.

Once the transition ramp has been placed over the adhesive, it should be allowed to fully cure before any compressive force is placed on it.

Recommended Trowles For Maximum Performance



1/8" x 1/8" x 1/8" - Coverage 90 ft2 per Gallon

Trowel size is suggested to maximize coverage of adhesive.
 Periodically check coverage of adhesive during installation.
 Uneven surfaces may require the use of either a leveling/patching material, or a larger notched trowel for proper coverage of adhesive.

Keystone and Strategic Tile Row Adhesion

Prior to adhering any tiles check the drawing to ensure that the installed tiles represent the intended design.

Ensure that the control lines have been properly marked based on the attached compression chart.

Trowel the factory supplied adhesive within the gridline location that will receive the tile. Ensure that troweled adhesive remains within the grid lines where strategic tile rows will be placed (*Fig. 12*).

Apply adhesive using a 1/8th inch V- notched trowel. Apply adhesive in increments covering only the areas that will receive tiles within 20 minutes of adhesive application.




Fig. 12

Note: The adhesive placed under keystone and strategic tiles must cure before compressive forces are applied.

Closing Statement

The entire Infinity Performance team wishes to thank you for your careful consideration and decision to purchase a Infinity MAX™ System. Your investment in a Infinity MAX™ floor is a wise one.

We work hard to produce the highest quality products and our dedication to customer service does not end with the sale of our flooring. As industry leaders we are committed to the long term success of your project.

We are available by phone at: 1-888-479-1017 from 8:00 am to 5:00 pm Monday through Friday.

INSTALLATION INSPECTION FORM

Email or Fax a copy to Infinity Performance, Inc at info@infinityperformance.com or 317.479.1018 (Fax)

Facility or Site Name:	Inspection Date/Time:
Address:	
Installation Date(s)	
Installation Company:	Crew Leader:
	Customer:
COMMENTS:	
Include list of all installation team members on site Include photos of li	before, during, and after installation • Record any site issues and how they were resolved
Certific	ation Agreement
l,Signature	/
	Print Name
	Infinity MAYM tiles under compression as explained in the instructions and


have read the installation instructions and have installed the Infinity MAX™ tiles under compression as explained in the instructions and compression table. I understand that after the job is installed that a measurement will be taken in the room to verify that compression was achieved. I further understand that if this floor is not installed correctly by my installers under the specified compression that it will void the 10 year material warranty.

MEASUREMENT CHART

Number of Tiles	Standard Measurement
1	1′ 11 7/8"
2	3′ 11 3/4"
3	5′ 11 5/8"
4	7′ 11 1/2"
5	9′ 11 3/8"
6	11′ 11 1/4"
7	13′ 11 1/8"
8	15′ 11"
9	17′ 10 7/8"
10	19′ 10 3/4"
11	21′ 10 5/8"
12	23′ 10 1/2"
13	25′ 10 3/8"
14	27′ 10 1/4"
15	29' 10 1/8" 31' 10"
16	31 10 33′ 9 7/8"
17 18	35' 9 3/4"
19	37' 9 5/8"
20	39' 9 1/2"
21	41′ 9 3/8"
22	43′ 9 1/4"
23	45′ 9 1/8"
24	47′ 9"
25	49′ 8 7/8"
26	51' 8 3/4"
27	53′ 8 5/8"
28	55′ 8 1/2"
29	57′ 8 3/8"
30	59′ 8 1/4"
31	61′ 8 1/8"
32	63′ 8"
33	65′ 7 7/8"
34	67′ 7 3/4"
35	69′ 7 5/8"
36	71′ 7 1/2"
37	73′ 7 3/8"
38	75′ 7 1/4"
39	77′ 7 1/8"
40	79′ 7"
41	81' 6 7/8"
42	83′ 6 3/4"
43	85′ 6 5/8"
44	87' 6 1/2"
45	89' 6 3/8"
46	91' 6 1/4"
47	93′ 6 1/8"
48	95′ 6"
49	97′ 5 7/8"
50	99′ 5 3/4"







I - Full Glue Down Installation Method

II - Adhesive Instructions

III - Installation Inspection Form

IV - Measurement Chart



Infinity Performance, Inc. 6735 N. Meridian Street Indianapolis, IN 46260 Phone: 317-479-1017 Toll Free: 888-479-1017 Fax: 317-479-1018